# Airflow Instructions

### Step 0 Airflow Installation

\$ pip install apache-airflow

#### Step 1: Airflow Initialization

 $\mathbf{a}$ 

In terminal, navigate to your favorite place and make a directory as the workspace for airflow.

```
$ cd /../Documents
```

\$ mkdir airflow\_tutorial

b

Set the AIRFLOW\_HOME environment to this directory.

```
$ export AIRFLOW_HOME=`pwd`/airflow_tutorial
```

 $\mathbf{c}$ 

Type the following two commands to initialize airflow in the folder.

```
$ airflow version
```

\$ airflow initdb

The second command will generate file airflow.cfg, unittests.cfg, airflow.db and a folder logs.

 $\mathbf{d}$ 

Start the Airflow webserver

```
$ airflow webserver
```

After this configuration, open your web browser and go to http://localhost:8080/admin/, you can see the web server of airflow with a bunch of default DAGs listed.

# Step 2: DAG – Directed Acyclic Graph

 $\mathbf{a}$ 

While keep the previous terminal window running, open a new terminal window and navigate to the work space and set the AIRFLOW\_HOME environment again.

```
$ cd /../Documents
```

\$ export AIRFLOW\_HOME=`pwd`/airflow\_tutorial

 $\mathbf{b}$ 

Navigate to the folder airflow\_test, and make another directory called 'dags'.

```
$ cd airflow_tutorial
$ mkdir dags
```

 $\mathbf{c}$ 

Open file **airflow.cfg** and make sure 'dags\_folder' is set to the folder you just created. Otherwise, change accordingly using the follow code.

```
dags_folder = /../Documents/airflow_tutorial/dags
```

 $\mathbf{d}$ 

In the dags folder, add the following code and save it as a python file called 'hellow\_world.py'

## Step 3: Push the DAG to the webserver.

a

Type the following code to push the dag to the webserver.

airflow scheduler

b

Refresh the webserver, and you should be seeing the following DAG that is just added.

| 1, | 0   | DAG         | Schedule   | Owner   | Recent Tasks 6 | Last Run | DAG Runs 6 | 2 3 Links<br>⊥ ⊥        |
|----|-----|-------------|------------|---------|----------------|----------|------------|-------------------------|
| Œ  | Off | hello_world | 0 12 * * * | Airflow |                |          |            | ⊙♦ <b>₩.IMI</b> ₩.A≘#≣S |

 $\mathbf{c}$ 

Click 1 to turn the DAG on, you might need to refresh the page after this. Then click 2 to run the DAG. Finally, you can click 3 to see the DAG and its status.



# A new DAG to build a pipeline

Now you just made airflow work on your machine, it's time to build up the first practical airflow pipeline.

 $\mathbf{a}$ 

Navigate to the airflow workspace you just created and make a new directory called 'tasks', where we will save three python files. Our goal is to use airflow to build a pipeline so that these three files will run automatically and consecutively.

```
$ cd /../Documents/airflow_tutorial
$ mkdir tasks
```

Save these three python files in this directory. These files will each write out a csv file as a result.

b

In the same 'dags' folder, create another file called 'csv\_writer.py', and paste in the code from here.

 $\mathbf{c}$ 

Then we just need to follow the same procedure as above to make it run. In a terminal window, run:

```
$ cd /../Documents
$ export AIRFLOW_HOME=`pwd`/airflow_tutorial
$ airflow webserver
```

Start a new terminal window, and do:

```
$ cd /../Documents
$ export AIRFLOW_HOME=`pwd`/airflow_tutorial
$ airflow scheduler
```

#### $\mathbf{d}$

Last, repeat Step 3(b) and 3(c) to finish running it in the webserver.